


Components



Item No.	Nominal length	Internal drawer length	Min.installation length of drawer
1	270mm	244mm	280mm
2	300mm	274mm	310mm
3	350mm	324mm	360mm
4	400mm	374mm	410mm
5	450mm	424mm	460mm
6	500mm	474mm	510mm
7	550mm	524mm	560mm

1.Cabinet profiles: (L/R)	6.204 Rear connecting bracket
2.Drawer profiles: (L/R)	7.Gallery tube
3.86 Rear connecting bracket	8.Middle tube
4.140 Rear connecting bracket	9.Front fixing brackets
5.164 Rear connecting bracket	10.Front panel

B86 Installation dimensions

Assembling dimensions of cabinet	Front fixing bracket	Drilling hole size on drawer front	Drawer back

B140 Installation dimensions

Assembling dimensions of cabinet	Front fixing bracket	Drilling hole size on drawer front	Drawer back

B164 Installation dimensions

Assembling dimensions of cabinet	Front fixing bracket	Drilling hole size on drawer front	Drawer back

B204 Installation dimensions

Assembling dimensions of cabinet	Front fixing bracket	Drilling hole size on drawer front	Drawer back


B120 Installation dimensions

Assembling dimensions
of cabinet


Front fixing bracket

Drilling hole size on
drawer front


Drawer back




Bottom and back panels measurement




Slide installation



Drawer assembly




Install assembly



Installation & Disassembling manual

Install wooden drawer front

Disassemble wooden drawer front




Drawer front adjustment

Wooden drawer front height
adjustment: $\pm 2\text{mm}$

Drawer front right
adjustment 1mm

Drawer front left
adjustment 1mm

Gradient adjustment



Install & Dismantle of drawer

1.Sliding out the slides

2.Method I : put the drawer from
the top onto the slide

3.Method II : put the drawer from
the front onto the slide

4.Lift the drawer up for dismantle

